

How to Read a Water Meter

Dial:

- The dial turns completely around once to register.
1 cubic foot = 7.50 gallons of water

Low Flow Indicator/ Leak Indicator:

- If all water is off inside the home and throughout the property, the Low Flow Indicator should not move.

If the water is off throughout the home and property, but the Low Flow Indicator is moving, water is still flowing through the meter, which may indicate a possible leak or running toilet.

Odometer/ Billable Units:

- The four (4) white squares/black numbers are the billable units on the meter.
- The black squares/white numbers must turn over 99 times before the 100 cubic feet indicator turns.

